



PuroClenz Mini (4 gram) Instructions:

The mini 4 gram tablets are used in 2 ways

A. Pretreatment Spray: these tablets are recommended for pre-treating vehicle interiors with moderate to severe odor issues before our powerful 20 gram, gas-off application and safe for all surfaces.

1. Fill spray bottle with 28-32 oz. of water
 2. Drop one 4-gram PuroClenz tablet, replace the spray nozzle cap, and wait for the water to turn yellow (approximately 2 minutes). PuroClenz is now active!
 3. Set the nozzle to spray/mist setting
 4. Keep spray nozzle 4-6 inches away and mist down the vehicle interior (dash, headliner, seats, carpet, etc.). Optional: lightly wipe down the hard surfaces (door panels, dashboard, etc) after the spray sits for a minute
 5. Now you are ready for the 20-gram PuroClenz gas-off application! (See 20 gram gas-off instructions to complete to PuroClenz process)
- You may store the spray bottle with any remaining PuroClenz in a cool, dark place. It will remain active for up to 6 weeks for additional use!

B. Mini Gas-off Application: these tablets can also be used to freshen up a stale vehicle or to treat very mild odor issues.

1. Important: to maximize the full effect of PuroClenz, do not treat the vehicle in direct sunlight
2. Using the PuroClenz cup, add water to the lower, black 4-gram fill line
3. Place the cup in a center console, armrest, or cup holder
4. Tear open the foil packet, place the PuroClenz Mini tablet into the cup of water, exit the vehicle, and close the door. (Make sure all doors are locked and windows are closed during treatment)
5. Allow PuroClenz to generate vapor for 30 minutes.

6. After the initial 30 minutes, start the vehicle to run the AC on high for 10 minutes. (Note: quickly enter and exit the vehicle as you perform this step)
7. Next, turn the recirculation button (shown below) on high and allow to run for 10 minutes



8. Once 10 minutes have passed on recirculation mode, turn the vehicle off, remove the PuroClenz cup, and dispose of the remaining liquid down the drain
9. At this point, your PuroClenz Mini application is complete! Optional: roll down the windows to air out any remaining vapors