

PURO CLENZ

PuroClenz Ultra Application for Vehicles (Extreme odor issues)

➤ It is recommended that you use the PuroClenz accelerator for optimal results

DO NOT treat a damp interior (Example: recently detailed vehicle).
Make sure interior is fully dry before application

1. Remove all personal belongings, floor mats, and any air fresheners from the vehicle (Important: to maximize the full effect of PuroClenz, do not treat vehicles in direct sunlight)
2. Make sure all doors and windows are closed during treatment
3. Open all air vents in the vehicle
4. Sun visors should be positioned half way down, in order to expose both sides of the visor. Any sunroof cover should be closed and all seat belts engaged for maximum exposure to the PuroClenz vapor
5. Place the PuroClenz “Warning Sticker” in a highly visible area of the vehicle to indicate that it is undergoing treatment
6. Using a 1-2 gallon plastic bucket, add approximately 2.5 quarts of water. Place bucket on passenger side floor (if using a PuroClenz Accelerator, it can be attached to the bucket and turned on at this step).
7. Tear open the foil pack, place the PuroClenz Mega 100-gram tablet into the bucket of water, exit the vehicle, and close the door (It is best to lock the doors and keep the keys during treatment so that nobody accidentally enters the vehicle)
8. Allow PuroClenz to generate vapor for 30 minutes
9. After the initial 30 minutes, start the vehicle to run the AC on high for 10 minutes. (Note: quickly enter and exit the vehicle as you perform this step)
10. Next, turn the recirculation button (shown below) on high and allow to run for 10 minutes



11. Once 10 minutes have passed on recirculation mode, turn the vehicle off, exit, shut the door and allow PuroClenz to remain inside the vehicle for 12-24 hours to more thoroughly eliminate odors
12. Once this treatment time expires, remove the PuroClenz cup and dispose of the remaining liquid down the drain
13. Return to the vehicle and open all windows and doors. Start the vehicle for another 20 minutes in order to "air out" any remaining vapors
14. As in Steps 9 and 10, turn on the AC and then the recirculation for 10 minutes each, so that any fumes within the ventilation can also be removed
15. Please leave all the windows open for at least an hour to properly allow the PuroClenz vapors to disperse outside the vehicle
16. FINISHED! The vehicle is now "PuroClenzed" and odor free. You will notice an odor that smells like Chlorine. This is normal and safe and will gradually dissipate. The Mega dose application usually requires additional time to air out.